

# Installation Instructions for Surecarb 90 Side Load Housing

## Pre-Filter Installation

1. Open hinged access door by loosening and removing star knobs. Swing door to operator to install filter(s) into track.
2. Once door is opened, carefully slide pre-filter(s) into the track until pre-filter rests against foamed metal back at end of the housing. Pre-filter(s) should also be flush with door opening to allow the door to close. If multiple pre-filter(s) are to be installed, pre-filter(s) should be flush against previously installed pre-filter. Pre-filter(s) should be installed (when possible) with pleats running in the vertical position.
3. Repeat process until all pre-filters have been installed in housing.

## Filter Installation



1. Open hinged access door by loosening and removing star knobs. Swing door back to install filters into track.
2. Once door is opened, carefully slide panel(s) into the track until panel rests against foam pad at back of housing. Panel should also be flush with door opening to allow the door to close.
3. Repeat process until all panels have been installed in housing.

